



About us:

CenturyPly Film Face Shuttering Plywood is every contractor's final choice. It's BWP (Boiling Water Proof) grade, powder-proof ply that is especially suited for use in concrete shuttering and framework. The ply withstands alternate wetting and drying conditions.

The solid surface of the plywood neither buckles under a load nor is disturbed by vibrations caused at the time of construction.

Uses:

- · Concrete shuttering and framework
- Create moulds into which concrete can be poured for casting various structures
- Due to the increased stability, this plywood is ideal for outdoor applications like building exteriors
- · Formwork for beams and pillars
- · Site offices and mezzanine floors

Features:

- · BWP Grade Plywood
- · Use of Phenol Formaldehyde adhesive for bonding of veneers
- · Bend Resistant
- · More number of plies, hence more strength
- Chemically treated for borer and termite resistance
- · High resistance to climatic conditions
- · Made from specially treated eco-friendly timber
- · Sides are protected with water-resistant sealant

Advantages

- Film faced plywood is durable. It has higher resin loading & enhanced with special chemicals to resist weather and microrganisms. It can also withstand chemicals. Hence, it lasts long.
- CenturyPly Film faced plywood is made for outdoor usages and it lasts for years
- The double end coating and Phenolic adhesives ensure less water absorption
- The plywood is warp free under ideal conditions
- · Maximum repetitions guaranteed

Technical Specifications*

	FF30	FF34
Weight (Kg)	30	34
No. of Layers	10	11
Timber	Hardwood	Hardwood
Thickness	+/- 5%	+/- 5%
GSM Paper	40	40
Density (Kg/M2)	800-850	900-950
Grade	BWP	BWP
Confirmed Repetitions*	20	30



Handling guidelines and precautions

- · Avoid dragging; don't drop from heights
- · After usage, sheets need to be dried properly before storing
- Sheets need to be stored in a clean and dry place on a flat surface under a shed
- · Vertical/inclined stacking/storage is to be avoided.
- Clean both the side surfaces with steel-brush/any proper tool and use Mould Oil after every usage
- Use sealant on cut edges
- Use sharp-pointed screws to fix the ply and fill up the holes with putty. Screw to be used at minimum 25mm inside the edge





Corporate Office

Century House,

P-15/1, Taratala Road, Kolkata - 700088

+91 33 39403950

1800-5722-122

f Century Plyboards India Limited

Centuryply Official

▶ CenturyPlyboards India Ltd

□ CenturyPlyIndia

in CenturyPlyboards (I) Limited